

DEPARTURE FLOW

- NAV PAGE > LSK 3L

MCDU should Default to NAV IDENT

- NAV IDENT > LSK 6R
- POS INIT > LSK 3R (GPS)
 - > LSK 6R
- FLT PLAN > LSK 6R
- PERF INIT & DATA > LSK 6R
 - + 3 DATA PAGES
- DEPARTURE > LSK 6R
- TAKE-OFF INIT & DATA
 - + 3 DATA PAGES